# **IDT-BPADAPT**


DP5012 - 01a - DI










# Bracket for ID84/ID84L/IDS312 to base plate VNT-BP600










## **Contents:**



Weight: 1.8 kg / 4 lb nexo-sa.com ZA du Pre de la Dame Jeanne 60128 PLAILLY - France




- Keep this document.

- Observe all warnings and cautions.



#### **Dimensions:**




Use:

IDT-BPADAPT must be used to secure ID84/ID84L/IDS312 to the base plate VNT-BP600 with a maximum of

- 1x ID84L + 1x ID84 (with IDT-COUPL).
- 2x ID84 (with IDT-COUPL).
- 1x IDS312 + 1x ID84 by using quick connect on IDS312.

Attach IDT-BPADAPT to IDS312 or ID84, then place the assembly on VNT-BP600. Tighten properly.



### **PRECAUTIONS**

Speaker must always be installed on a horizontal surface.

Ensure that audience is not allowed within a safety area which radius is equal or higher than assembly height.

- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site nexo-sa.com for the latest update.





- Keep this document.

- Observe all warnings and cautions.

