
DP2254 - 01a - DI







Flight Case For 3x GEOM10




Dimensions:





Weight: 40 kg / 88 lb






Keep this document.Observe all warnings and cautions.





Use:

- Put back up the flight
- > Open the 'L' cover
- > Mounting the Bumper (GMT-LBUMPM10 / VNT-BUMPM10) and if necessary the extension bar (GMT-EXBARM10L / VNT-EXBARM10)

HF on the left	HF on the right
Take out GEOM10 link bar;	AutoRig™ in Autolock™ status;
Place the Bumper;	Place the Bumper;
Front: lock with quick release pins;	Check that it is properly engaged;
Adjust the angle with the Bumper link bar;	Adjust the angle with Bumper link bar;







- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site <u>www.nexo-sa.com</u> for the latest update.



- Read this document before using.
- Keep this document.
- Observe all warnings and cautions.

