













Installation Bumper for GEOM10 - MSUB15




Contents:

<b>X1</b> 		<b>X2</b> 	<b>X3</b> 
<b>X8 M8</b> 	<b>X11 M8</b> 	<b>X2 D12x35</b> 	<b>X2 M10</b> 
<b>X2 M8x45</b> 	<b>X1 D8x20</b> 	<b>X1 M6</b> 	<b>X1 M6</b> 

Weight: 18 kg / 40 lb


## Dimensions:



## Features:


- **Front rigging point**

Front rigging point are easily configurable. Adjust the front rigging point and lock with provided screws (screws M8x45, washers M8, brake nuts M8).




- **Hanging**

On the front and the rear of the frame, you find a lift ring. Use the provided quick links to hang up.



Place VNT-EXBARM10, lock with the provided fasteners (shoulder screws D12x35, brake nuts M10).



# NEXO

nexo-sa.com  
ZA du Pre de la Dame Jeanne  
60128 PLAILLY - France


- Read this document before using.
- Keep this document.
- Observe all warnings and cautions.



## Use:

- **With MSUB15**

Place the Bumper on or under the MSUB15, insert the axis and the washers (M8) and secure with the brake nuts (M8).




- **With GEOM10**

Remove the front skids to allow the adjustment of certain angles with the first GEO M10.

Place the Bumper on or under the GEOM10, insert the axis and the washers (M8) and secure with the brake nuts (M8).

Adjust the appropriate inter-angle value with the Linkbar and secure with the provided screws (1 shoulder screw D8x20, washer M8, washer M6, brake nut M6)



# NEXO

nexo-sa.com  
ZA du Pre de la Dame Jeanne  
60128 PLAILLY - France

- Read this document before using.
- Keep this document.
- Observe all warnings and cautions.





- Linkbar

Remove the screw and the nut to unlock the Linkbar.

Used for stack or flown with the first GEOM10.

- Below to flown (HANGING).
- Above to stack (STACKING).



HANGING		STACKING
Z	+12°	N
X	+9°	P
V	+6°	Q
T	+3°	R
S	0°	S
R	-3°	T
Q	-6°	V
P	-9°	X
N	-12°	Z

**WARNING:** Use NEXO Simulation Software for mechanical prediction

*Use only provided fasteners with VNI-BUMPM10.*

- NEXO cannot accept responsibility for accidents caused by any factor other than defects in this product itself.
- Please check the web site [nexo-sa.com](http://nexo-sa.com) for the latest update.